

RECYCLING



Meaning of crossed – out wheeled dustbin:


Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.



INSTRUCTION MANUAL

MARBLE CUTTER TSE15-M-EU

เครื่องตัดหินอ่อน 4" 1500 วัตต์ รุ่น TSE15-M-EU



SPECIFICATION


Model	TSE15-M-EU
Rated power	1500W
Rated voltage	220-240V~
Frequency	50/60Hz
No-load speed	14000rpm
Dia. of saw blade	Ø115mm
Max.depth of cutting	34mm
Net. Weight	3.58 KG

⚠ WARNING!

When working with electrical device the following prevention and safety instructions are to be observed to avoid fires, electric shocks and physical injuries.

KNOW YOUR WALL CHASER

- 1) Lock on button
- 2) Switch trigger
- 3) Depth adjustment knob
- 4) Saw blade
- 5) Outer flange
- 6) Fix screw of saw blade



GENERAL POWER TOOL SAFETY WARNINGS

Read all safety warnings and all instructions. Failure to follow all warnings and instructions may result in electric shock, fire and/or serious injury. Save all warnings and instructions for future reference. The term “power tool” in the warnings refers to your mains operated (corded) power tool or battery operated (cordless) power tool.

■ WORK AREA

- Keep work area clean and well lit. Cluttered and dark areas invite accidents.
- Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
- Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.

■ ELECTRICAL SAFETY

- Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
- Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
- Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord for carrying, pulling

or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.

- When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.

- If operating a power tool on a damp location is unavoidable, use a residual current device (RCD) protected supply. Use of an RCD reduces the risk of electric shock.

PERSONAL SAFETY

- Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.

- Use safety equipment. Always wear eye protection. Safety equipment such as dust mask, non-skid safety shoes, hand hat, or hearing protection used whenever conditions require will reduce personal injuries.

- Avoid accidental starting. Ensure the switch is in the off position before plugging in.

- Carrying power tools with your finger on the switch or plugging in power tools that have the switch on invites accidents.

- Remove any adjusting key or wrench before turning the power tool on. A wrench or a key left attached to a rotating part of the power tool may result in personal injury.

- Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.

- Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts.

- If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of these devices can reduce dust related hazards.

POWER TOOL USE AND CARE

- Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate of which it was designed.

- Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.

- Disconnect the plug from the power source before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.

- Store idle power tool out of the reach children and do not allow persons unfamiliar with the power tool or these instructions to operate the power tool. Power tools are dangerous in the hands of untrained users.

- Maintain power tools. Check for misalignment or sticking of moving parts, breakage of parts and other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.

- Keep cutting tools sharp and clean. Properly maintained cutting tools with cutting edges are less likely to stick and are easier to control.

- Use the power tool, accessories and tool bits etc., in accordance with these instructions and in the manner intended for the particular type of power tool, taking into account the working conditions and the work to be performed. Use of the power tool for operations different from intended could lead to a hazardous situation.

■SERVICE


Have your power tool serviced by qualified repair person using only identical replacement parts. This will ensure that the safety of the power tool is maintained.

OPERATION & USE

■ASSEMBLY AND ADJUSTMENTS

⚠ WARNING!

Prior to assembly and adjustment, always unplug tool.



- To remove and install the blade

- 1) Place saw on a stable surface.
- 2) To remove the blade, hold the outer flange, using the wrench provided. Remove the blade screw by turning it clockwise.
- 3) To install the blade, reverse this procedure.


OPERATION

⚠ WARNING!

Always observe the safety instructions and applicable regulations. Use the appropriate blade. Do not use cracked, damaged or excessively worn blade.

Wait for the blade to reach the maximum speed and use a slow even feed for proper cutting.

■SWITCHING ON AND OFF



- 1) To operate your tool, press the on/off switch.
- 2) For continuous operation, press the lock-on button and release the switch. To disengage the locking button, depress then release the switch.

■ADJUST THE DEPTH GAUGE FOR STRAIGHT CUTS

- 1) Release the depth adjustment knob.
- 2) Pull the base plate to the desired position.
- 3) Tighten the knob.

